

Manual, Assembly instruction: Brodit 854546

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the upper part of the ProClip into the upper part of the air vent so the ProClip edge meets the chrome trim.

2. Press forward on the lower part of the ProClip so the angled edge goes into the seam/gap between the air vent edge and the chrome trim. Press until you see or hear/feel it click into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.