

Manual, Assembly instruction: Brodit 854547

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hold the ProClip in an almost 45 degree angle towards the center console. Press the curved edge on the left side of the ProClip into the seam/gap between the center console panel frame and the console edge.

2. Place your thumb on the right side of the ProClip and your index finger around the console edge in the sidewall. Clam your fingers together so the ProClip goes forward and the angled edge hooks around the console edge.

3. The ProClip mount is in place.

4. The ProClip mount is in place.