

Manual, Assembly instruction: Brodit 854548

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the seam/gap between the stereo/navigation and the surrounding panel frame.

2. Press firmly forward on the upper part of the ProClip so it flexes forward, and the angled edge on the back part of the ProClip hooks around the compartment edge. Press down on top of the ProClip for best possible attachment of the adhesive tape.

3. The ProClip mount is in place.

4. The ProClip mount is in place.