

Manual, Assembly instruction: Brodit 854555

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper part of the ProClip into the upper part of the air vent, so the edge meets the surrounding frame.

2. Hold the upper part of the ProClip in that position and press the lower part upward so the ProClip flexes.

3. Place the lower part of the ProClip into the lower part of the air vent, so the edge meets the surrounding frame. Release the pressure so the ProClip is locked into place and the adhesive tapes attach.

4. The ProClip is in place.