


Manual, Assembly instruction: Brodit 854561

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip allows for horizontal devices up to 130 mm (5 inches) wide to be attached without preventing the center console compartment door to be opened and closed freely. Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip allows for horizontal devices up to 130 mm (5 inches) wide to be attached without preventing the center console compartment door to be opened and closed freely.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the narrow back part of the ProClip into the 7th notch in the air vent counting from right to left.

2. Press down and hook the angled part of the ProClip around the 7th "sidewall" in the air vent.

3. Place your fingers behind the face plate part of the ProClip and pull it so it flexes towards you. Hook the angled lower edge around the upper air vent edge.

4. The ProClip is in place.