

Manual, Assembly instruction: Brodit 854563

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the grooved edge on the right part of the ProClip into the gap above the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the stereo. Press forward on the left part of the ProClip so the angled edge goes all the way into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.