

Manual, Assembly instruction: Brodit 854567

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the upper part of the ProClip into the upper part of the air vent housing.
2. Press the angled edge on the upper part of the ProClip upward into the gap between the air vent housing and the surrounding frame.
3. Press the lower part of the ProClip upward and forward. Hook the thin lower edge into the gap between the air vent housing and the surrounding frame.
4. The ProClip is in place.