

Manual, Assembly instruction: Brodit 854569

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip over the frame surrounding the air vent.
2. Press downward on the upper part of the ProClip so the ProClip flexes slightly. Then press the upper part forward into the air vent, so the angled edge is placed under the frame surrounding the air vent.
3. Release the pressure so the angled upper edge hooks under the frame surrounding the air vent.
4. The ProClip is in place.