

Manual, Assembly instruction: Brodit 854571

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the center console and the surrounding frame.
2. Press forward on the right side of the ProClip so the angled edge hooks around the console frame edge.
3. Press the right side of the ProClip toward the center console sidewall so the angled edge hooks into place properly.
4. The ProClip is in place.