

Manual, Assembly instruction: Brodit 854583

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the center console side wall, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the curved edge on the right part of the ProClip into the gap next to the gap opener. Flip the ProClip leftward, toward the steering wheel, so the curved right edge hooks into the gap.

3. Hook the angled edge on the left part of the ProClip into the gap between the control panel and the surrounding frame. Press forward on the left part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.