

Manual, Assembly instruction: Brodit 854585

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the center panel and the dashboard.

2. Press the angled edge on the lower part of the ProClip all the way into the gap. Pull the upper part of the ProClip upward and press it forward.

3. Hook the angled edge on the upper part of the ProClip over the panel. Press down on top of the ProClip so the angled edge hooks into place properly.

4. The ProClip is in place.