

Manual, Assembly instruction: Brodit 854588

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the left part of the ProClip into the gap between the control panel and the center console frame.
2. Flip the right part of the ProClip forward so the angled edge on the left part hooks behind the control panel.
3. Press forward on the right side of the ProClip so the angled edge hooks around the center console frame. Press until you hear/feel it snaps into place.
4. The ProClip is in place.