

Manual, Assembly instruction: Brodit 854590

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the upper part of the ProClip into the gap between the gap openers. Pull out the gap openers.
3. Pull the ProClip downward and hook the lower edge under the panel surrounding the air vent.
4. The ProClip is in place.