

Manual, Assembly instruction: Brodit 854595

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the trim surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the left part of the ProClip into the gap between the center console and the dashboard.

2. Flip the right part of the ProClip forward so the curved left edge hooks behind the center console.

3. Press forward on the right part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.