

Manual, Assembly instruction: Brodit 854603

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: It is important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the curved edge on the lower part of the ProClip into the gap between the trim and the lower dashboard section, in the exact same position as the arrows show in the picture.

2. Press the curved edge on the lower part of the ProClip into the gap between the trim and the dashboard. Flip the upper part of the ProClip upward/forward so the curved lower edge hooks behind the dashboard.

3. Hook the angled edge on the upper part of the ProClip over the lower edge of the air vent. Press down on top of the ProClip so the adhesive tape attaches.

4. The ProClip is in place.