

Manual, Assembly instruction: Brodit 854607

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel.
2. Press the ProClip upward and the upper part forward.
3. Press downward on top of the ProClip so the curved edge hooks under the frame surrounding the air vent.
4. The ProClip is in place.