

Manual, Assembly instruction: Brodit 854612

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be place both on the left and the right air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed angled gap opener upward into the gap between the air vent and surrounding frame, to widen the gap. Peel off the adhesive tape cover on the ProClip.

3. Press the gap opener upward into the gap. In the same time: Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the lower part of the ProClip upward and then forward. Hook the angled lower lower edge on the ProClip over the edge surrounding the air vent.

4. The ProClip is in place.