

## Manual, Assembly instruction: Brodit 854614

Angled mount, High

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Place it in the lower right corner. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

**2.** Flip the ProClip upward/forward so the curved lower edge goes all the way into the gap and hooks behind the dashboard. Pull out the gap opener.

**3.** Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Pull the upper part of the ProClip upward and hook the angled edge into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

**4.** The ProClip is in place.