

Manual, Assembly instruction: Brodit 854623

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin angled edge of the enclosed gap opener downward into the gap between the frame surrounding the information window and the surrounding panel, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip downward so the curved upper edge hooks behind the frame surrounding the information window. Pull out the gap opener.

3. Pull the ProClip toward you and hook the angled lower edge under the upper edge of the air vent.

4. The ProClip is in place.