

Manual, Assembly instruction: Brodit 854625

Center mount, High, Right



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the frame surrounding the center console, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Hook the grooved edge on the lower part of the ProClip under the upper edge of the air vent. Adjust the ProClip position until you hear/feel that the grooved edge hooks into place properly.
3. Pull the upper part of the ProClip upward and hook the angled upper edge into the gap next to gap opener. Pull out the gap opener.
4. The ProClip is in place.