

Manual, Assembly instruction: Brodit 854626

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard ledge, to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the lower part of the ProClip into the gap next to the gap opener.

2. Press the upper part of the ProClip downward so the ProClip flexes a bit. In the same time: press the ProClip forward so the lower edge goes into the gap next to the gap opener and the upper edge goes into the upper part of the air vent. Release the pressure when you see that the lower edge is all the way into the gap and the upper edge rests on the frame surrounding the air vent. Pull out the gap opener.

3. You can choose to place this ProClip onto the right air vent, or to have two ProClips installed at the same time.

4. The ProClip is in place.