

## Manual, Assembly instruction: Brodit 854629

Center mount NOT for models with factory navigation.



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap on top of the dashboard, to widen the gap between the center console and the dashboard. Press the gap opener downward to widen the gap a bit more and in the same time hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Hook all of the angled edge under the center console. Pull out the gap opener.

2. Press the gap opener into the gap between the control panel and the center console. Pull the ProClip toward you and downward and hook the angled lower edge into the gap next to the gap opener.

3. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.