

Manual, Assembly instruction: Brodit 854631

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the panel surrounding the air vent and the frame surrounding the display.
2. Pull the lower part of the ProClip downward, then press it forward. Hook the angled lower edge into the gap between the panel surrounding the air vent and the center console.
3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches.
4. The ProClip is in place.