

## Manual, Assembly instruction: Brodit 854633

Center mount MAY block information display.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the thin end of the right part of the ProClip into the gap above the gap opener.

**2.** Press the left part of the ProClip rightward, and then forward. Hook the angled left edge of the ProClip into the gap between the air vent and the surrounding frame.

**3.** Place your finger inside the ProClip and press the left part leftward so the adhesive tape attaches. Pull out the gap opener.

**4.** The ProClip is in place.