

Manual, Assembly instruction: Brodit 854636

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the thin upper part of the ProClip into the upper part of the air vent.
2. Push the lower part of the ProClip upward and hook the grooved edge onto the lower air vent edge.
3. The ProClip is in place.
4. The ProClip is in place.