

Manual, Assembly instruction: Brodit 854638

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the upper part of the ProClip around the dashboard edge by the air vent.
2. Place your index fingers behind the ProClip.
3. Pull the ProClip so it flexes towards you and then hook the angled edge around the dashboard edge.
4. The ProClip is in place.