

Manual, Assembly instruction: Brodit 854639

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the coin box edge and the surrounding panel frame, to widen the gap. Keep the gap opener in this position and then press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Place your fingers on top of the ProClip and press down. Hook the angled edge into the gap between the coin box and the surrounding panel frame. Let go of the pressure so the angled edge goes all the way into the gap.

3. The ProClip mount is in place.

4. The ProClip mount is in place.