

Manual, Assembly instruction: Brodit 854641

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the curved edge on the lower part of the ProClip around the upper air vent edge.

2. Hold the enclosed gap opener in an angled position and press the thin end into the seam/gap on top of the dashboard, to widen the gap. Hold the gap opener in this position and then push forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.