

Manual, Assembly instruction: Brodit 854643

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the right side of the ProClip into the seam/gap between the center console panel frame and the padded part of the dashboard.

2. Flip the ProClip to the left so the curved edge on the right side of the ProClip hooks behind the center console panel frame.

3. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the padded part of the dashboard, to widen the gap. Press firmly forward on the left side of the ProClip so the grooved edge goes into the gap below the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.