

Manual, Assembly instruction: Brodit 854645

Center mount ONLY for models with tilt down information screen.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Open the front of the stereo. Place the thin end on the lower part of the ProClip underneath the air vent overhang. NOTE: The stereo screen does not interfere or touch the ProClip when being opened and closed.

3. Place your index fingers underneath the upper part of the ProClip. Pull, so it flexes upward. Hook the angled edge into the gap next to the gap opener. Press down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.