

Manual, Assembly instruction: Brodit 854646

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the seam/gap between the air vent house and the surrounding panel frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the seam/gap between the air vent house and the surrounding panel frame. Place your fingers on the top part of the ProClip. Push down, so it flexes downward, and then hook the angled edge into the gap next to the gap opener. Let go of the pressure on the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.