

Manual, Assembly instruction: Brodit 854647

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the seam/gap between the climate control panel and the center console panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the lower part of the ProClip into the seam/gap next to the gap opener.

2. Flip the ProClip upward, towards the air vent, and at the same time press forward on the lower part of the ProClip so the lower curved edge goes all the way into the gap and hooks behind the climate control panel. Pull out the gap opener.

3. Place your fingers underneath the ProClip. Push so the ProClip flexes upward and then hook the angled edge around the lower air vent edge. Press down on top of the ProClip to make sure the ProClip is properly attached to the lower air vent edge.

4. The ProClip is in place.