

Manual, Assembly instruction: Brodit 854650

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the climate control and the surrounding panel frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the tip of the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip upward, towards the air vent, and at the same time, press forward on the lower part of the ProClip so the curved edge goes all the way into the gap.

3. Place your index fingers underneath the upper part of the ProClip. Pull so it flexes upward and then hook the angled edge over the lower air vent edge. Press firmly down on top of the ProClip for best possible attachment of the adhesive tape. Pull out the gap opener.

4. The ProClip is in place.