

Manual, Assembly instruction: Brodit 854651

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of one of the the enclosed gap openers into the gap in the center console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Position the ProClip so the lower left corner is just above the seam/gap between the two sidewall sections.

2. Press the thin end of the second gap opener into the seam/gap between the climate control panel and the padded console edge, to widen the gap. Keep the alignment of the ProClip as advised above and then press the the curved edge into the gap below the gap opener. Flip the ProClip to the right so the curved edge on the left side of the ProClip hooks behind the climate control panel.

3. Place your left index finger behind the ProClip and find the left corner of the horizontal part on the inside of the ProClip. "Steer" the left corner of the horizontal part into the gap in the sidewall. Press it all the way into the gap with your thumbs. Move your hands further back on the ProClip and press firmly forward so the remaining part of the horizontal part goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.