

Manual, Assembly instruction: Brodit 854652

Angled mount ONLY for models with 4,3" display.



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip fits models with or without factory navigation & information screen. This ProClip is divided into two parts: Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip fits models with or without factory navigation/information screen. This ProClip is divided into two parts: Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Press the thin end of the enclosed gap openers into the gap between the center console panel frame and the console edge, to widen the gap.

2. Peel off the cover of the adhesive tape on Part 1. Place the thin edge of Part 1 against the gap between the two gap openers. The tape on the thick part of Part 1 should be facing the passenger side. Press the thin edge firmly into the gap and at the same time: bend Part 1 to the right until you see or hear/feel it click into place. The adhesive tape will attach to the console edge. Pull out the gap openers.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Do not press the tape to the center console panel frame yet. Screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws press the ProClip to the right with your thumb for optimal adjustment of the mount. Then press the adhesive tape on the left side of Part 2 to the center panel. Hold the ProClip in that position and tighten the screws.