

Manual, Assembly instruction: Brodit 854653

Center mount ONLY for vertically positioned devices.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin edge on the right side of the ProClip into the gap between the panel surrounding the air vent and the panel surrounding the stereo.

2. Press firmly forward on the left side of the ProClip so the angled edge hooks around the panel edge in the air vent. Press until you see or hear/feel it click into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.