

Manual, Assembly instruction: Brodit 854656

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin angled edge on the upper part of the ProClip into the seam/gap between the air vent and the surrounding panel frame. Note: You may have to wiggle the ProClip a little to get the edge to go into the gap.
2. Push firmly on the bottom part of the ProClip so it flexes upward and then hook the angled edge into the seam/gap between the air vent and the surrounding panel frame.
3. Press down on the inside of the ProClip to make sure the angled edge is all the way into the gap.
4. The ProClip is in place.