

Manual, Assembly instruction: Brodit 854658

Center Mount ONLY for models with factory navigation or information screen.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the two dashboard panel sections, to widen the gap.
2. Place/hook the angled edge on the lower part of the ProClip around/into the upper air vent edge
3. Press on the upper part of the ProClip so it flexes forward and the angled edge hooks into the gap next to the gap opener. Press down on top of the ProClip, by the gap opener, to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.