

Manual, Assembly instruction: Brodit 854662

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the seam/gap in the console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Press the thin end of the angled edge on the left side of the ProClip into the gap between the CD player and the surrounding panel frame.
3. Place your thumb on the right front side of the ProClip (behind the face plate). Push so the ProClip flexes forward and the angled edge goes into the gap above the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.
4. The ProClip is in place.