

Manual, Assembly instruction: Brodit 854664

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the curved edge on the right side of the ProClip around the center console frame in the console sidewall.
2. Push firmly leftward on the right side of the ProClip so it flexes to the left.
3. Hook the angled left edge of the ProClip around the console edge by the gear shift.
4. The ProClip is in place.