

Manual, Assembly instruction: Brodit 854665

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the lower part of the ProClip into the bottom part of the air vent. Press it down into the seam/gap between the air vent and the surrounding panel frame. Note: if the angled edge is hard to get into the gap, pull the panel frame firmly towards to widen the gap slightly and then press the angled edge into the gap.

2. Press firmly down on top of the ProClip so it flexes downward. Hook the angled edge into the seam/gap between the air vent and the surrounding panel frame.

3. Place your thumb underneath the upper part of the ProClip. Push upward to make sure the angled edge is all the way into the gap.

4. The ProClip is in place.