

Manual, Assembly instruction: Brodit 854669

Angled mount NOT for models with factory navigation.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the seam/gap between the stereo and the surrounding panel frame.

2. Press firmly forward on the right side of the ProClip so the angled edge hooks around the console panel edge

3. Press the upper edge on the ProClip towards the dashboard to make sure it is properly hooked around the panel edge. Close the glove compartment door.

4. The ProClip is in place.