

Manual, Assembly instruction: Brodit 854671

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the two dashboard sections, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the thin angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the two dashboard sections. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.