

Manual, Assembly instruction: Brodit 854676

Center mount ONLY for wood grain panel.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. The pictures show an interior without wood grain panel, but the same installation instructions applies also for models with wood grain panel.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Press forwards on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener.

3. Press alternately forward on the left and right side of the upper part of the ProClip. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.