

Manual, Assembly instruction: Brodit 854678

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin edge of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap in the center console sidewall. Press forward on the right side of the ProClip so the angled right edge hooks into the gap above the gap opener. Press the right part of the ProClip toward the center console so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.