

Manual, Assembly instruction: Brodit 854684

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the dashboard and the control panel.
2. Press the lower part of the ProClip forward and hook the angled edge into the gap between the dashboard and the center console.
3. Press upward on the lower part of the ProClip so the angled edge hooks into place properly.
4. The ProClip is in place.