

Manual, Assembly instruction: Brodit 854686

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap between the dashboard and the center console.
2. Flip the ProClip upward/forward so the curved lower edge hooks behind the center console.
3. Hook the angled edge on the upper part of the ProClip into the gap between the dashboard and the control panel.
4. The ProClip is in place.