

Manual, Assembly instruction: Brodit 854689

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin angled edge of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip upward into the gap between the air vent and the surrounding frame.

2. Press the lower part of the ProClip upward and hook the angled edge into the gap next to the gap opener. Press downward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

3. This ProClip can also be placed onto the right air vent.

4. The ProClip is in place.