

Manual, Assembly instruction: Brodit 854691

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the air vent and the surrounding panel. Pull the ProClip toward you so the panel flexes and the gap is slightly widened. Then press the ProClip leftward so the angled edge goes all the way into the gap.

2. Press the ProClip leftward and hook the angled edge on the right part into the gap between the air vent and the panel surrounding the stereo.

3. Pull the ProClip toward you so the panel flexes and the gap is slightly widened. Then press the ProClip rightward so the angled edge goes all the way into the gap.

4. The ProClip is in place.