

Manual, Assembly instruction: Brodit 854693

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the stereo, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip downward/forward so the curved upper edge hooks behind the stereo.

3. Hook the angled edge on the lower part of the ProClip into the gap between the upper and lower section of the center console. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.